



SERVICE PACKAGES: 2023-2024 OUTLANDER PHEV /

PHEV PACKAGES	MONTHS OR KMS	
SERVICE 1 <ul style="list-style-type: none"> Rotate Tires Replace Engine Oil and Filter 	<ul style="list-style-type: none"> → 5 months or 8,000 KM → 15 months or 24,000 KM → 25 months or 40,000 KM → 35 months or 56,000 KM → 45 months or 72,000 KM → 55 months or 88,000 KM 	<ul style="list-style-type: none"> → 65 months or 104,000 KM → 75 months or 120,000 KM → 85 months or 136,000 KM → 95 months or 152,000 KM → 105 months or 168,000 KM → 115 months or 184,000 KM → 125 months or 200,000 KM
SERVICE 2 <ul style="list-style-type: none"> Rotate Tires Replace Engine Oil and Filter Replace Cabin Air Filter PHEV Multi Point Inspection 1 to 6 	<ul style="list-style-type: none"> → 10 months or 16,000 KM → 30 months or 48,000 KM → 50 months or 80,000 KM → 70 months or 112,000 KM 	<ul style="list-style-type: none"> → 90 months or 144,000 KM → 110 months or 176,000 KM → 130 months or 208,000 KM
SERVICE 3 <ul style="list-style-type: none"> Rotate Tires Replace Engine Oil and Filter Replace Cabin Air Filter Replace Engine Air Filter PHEV Multi Point Inspection 1 to 14 	<ul style="list-style-type: none"> → 20 months or 32,000 KM → 40 months or 64,000 KM → 60 months or 96,000 KM 	<ul style="list-style-type: none"> → 80 months or 128,000 KM → 100 months or 160,000 KM → 120 months or 192,000 KM

PHEV MULTI POINT INSPECTION ITEMS	
<ol style="list-style-type: none"> Check front & rear motor cooling oil leaks Check front & rear transaxle oil level & condition Inspect disc brake pads & rotors for wear Check brake hoses for deterioration or leaks Inspect drive shaft boots for grease leaks & damage Check tire repair sealant expiration date Check fuel hoses condition 	<ol style="list-style-type: none"> Check drive belts condition Check & service exhaust system Check rear motor coolant level & condition Inspect coolant hoses condition Inspect high voltage wire for looseness & damage Inspect ball joint & steering linkage seals for grease leaks & damage Inspect suspension system for looseness & damage

***At every 15 months or every 24,000 KM:** Replace KOS transmitter battery

***At every 30 months or every 48,000 KM:** Change brake fluid

***At every 45 months or every 72,000 KM:** Check evaporative emission control system for leaks & clogging, Inspect & adjust intake & exhaust valve clearance, Check fuel system for leak

***At 96 months or 192,000 KM:** Change engine coolant

***At 105 months or 168,000 KM:** Replace spark plugs, iridium tipped type