



SERVICE PACKAGES: TURBO - EVO & RALLIART /

PACKAGES	MONTHS OR KMS (WHICHEVER COMES FIRST)	
PACKAGE A • Replace engine oil & filter	→ 3 Months or 5,000 km → 9 Months or 15,000 km → 18 Months or 30,000 km → 24 Months or 40,000 km → 33 Months or 55,000 km	→ 39 Months or 65,000 km → 48 Months or 80,000 km → 54 Months or 90,000 km → 63 Months or 105,000 km → 69 Months or 115,000 km
PACKAGE B • Replace engine oil & filter • Inspection 1 to 7	→ 6 Months or 10,000 km → 21 Months or 35,000 km → 36 Months or 60,000 km	→ 51 Months or 85,000 km → 66 Months or 110,000 km → 81 Months or 135,000 km
PACKAGE C • Replace engine oil & filter • Inspection 1 to 15	→ 12 Months or 20,000 km → 27 Months or 45,000 km → 42 Months or 70,000 km	→ 57 Months or 95,000 km → 72 Months or 120,000 km → 87 Months or 145,000 km
PACKAGE D • Replace engine oil & filter • Brake service • Inspection 1 to 15	→ 15 Months or 25,000 km → 30 Months or 50,000 km → 45 Months or 75,000 km	→ 60 Months or 100,000 km → 75 Months or 125,000 km → 90 Months or 150,000 km

INSPECTION ITEMS	
1. Inspect disc brake pads and rotors 2. Check brake hoses for deterioration and leaks 3. Inspect driveshaft boots for grease leaks and damage 4. Check manual transaxle / transmission oil (if equipped) 5. Check transfer case oil (if equipped) 6. Check rear axle oil level 7. Check drive belt condition 8. Inspect ball joints and steering linkage seals for leaks and damage	9. Inspect suspension for looseness and damage 10. Inspect rear drum brake linings and rear wheel cylinders (except vehicles with disc brakes) for wear and leaks 11. Inspect condition on all coolant hoses (radiator and heater) 12. Inspect exhaust system 13. Audible valve clearance inspection 14. Check reserve tank fluid level for all wheel control pump 15. Check twin clutch sportronic shift transmission for leaks (check oil level)

The following services may be required on a VIN specific level at various maintenance intervals for your vehicle:

- Replace Brake Fluid
- Replace Transmission Fluid
- Replace Rear Differential Fluid
- Replace Transfer Case Fluid
- Replace Coolant
- Replace Iridium Spark Plugs
- Inspect Rear Axle Oil Level
- Replace drive belts
- Tire Rotation